

## Mounting the Éric Grauffel Signature GunCam to Your Cap



- 1 Use the hex key to loosen the Clip Mount hinge. Pull up the U-shaped camera grip.
- 2 With the hex key, remove the screw and separate the top part of the mount from the clip.
- 3 4 Fasten the mount through the bill of the cap using the included screw and nut.
- 5 Adjust the angle of the camera and tighten the hinge with the hex key. Don't overtighten.
- 6 We suggest that you use the rubber cover to keep dust off of your GunCam.



To mount the Éric Grauffel Signature GunCam to your cap as Éric does, you may use your Tripod Mount instead of the Clip Mount. You will need a short bolt (not included) that matches the standard tripod size of 1/4-20 (1/4" diameter, 20 threads per inch)

Screw it through the bottom of the cap's bill, and up into the bottom of the Tripod Mount. You will need to make a wider hole in the bill than you see above.

Although you will be unable to adjust the angle as with the Clip Mount, adjusting the cap on your head can also give you the desired angle for recording your shooting.

